


# BT3 Troubleshooting

Malfunction as Follow :




## Action :


1. Remove the gasket and remove the screw with a screwdriver



- 2, with the card surface and the bottom shell separation



3、 Gently remove the antenna and snap motherboard screws



4、 Remove the battery snap and plug in the power

**Note** : plug in the power sustained light lamp for 5 seconds, then go off, this is normal!

